


Garmin eTrex Units

Start-up Sequence

1. Press the Power button- right-hand side, bottom button.
2. Main screen will come up and say “Wait... Tracking Satellites”
3. When screen says “Ready to Navigate,” you are ready to go!




Finding a Waypoint


1. Press the bottom button on the left-hand side. The button has a magnifying glass underneath it.




2. The Find menu will pop up. Choose “Waypoints.” Then “By Name.”



3. Begin to type in the name of the waypoint that you are assigned to find. The name of your waypoint is on the orange sticker on your GPS unit. To type, move the pivot button (left, right, up, or down) to get to the letter, then press the pivot button in.
4. Press Ok to close the keyboard and choose the waypoint by pressing the pivot button in.



5. Click "Go To." A compass will appear. You usually have to start walking for the compass to correct itself. The number at the top right of the compass tells you your distance to the cache.



Press Go To



Distance to destination

Marking a Waypoint

1. Walk to location you want to mark
2. Press and hold in Pivot button (only button above screen).
3. Mark Waypoint screen (with a kneeling man and flag) will show up.
4. Use the Pivot button to scroll up and highlight the name of the flag.
5. Press Pivot button in to select and name the waypoint. A keyboard will appear.
6. Type in name assigned by leader/teacher.
7. Click OK on keyboard- this closes the keyboard.
8. MOST IMPORTANT- scroll to the bottom right of the screen and click "Ok." This saves the location.
9. Write down the coordinates of your cache.

Last thing, don't forget to turn unit off!